

Logging in and out of your IP Telephone

For the Aastra 6735i (black telephone)

Logging in:

1. Press the *Login/Logga in* button
2. Enter your extension number
3. Push *OK* in the display
4. Enter your four-digit PIN code
5. Push *OK* in the display

Logging out:

1. Press the *Logout/Logga ut* button
2. Press *Select/Välj* in the display

For the Aastra 6753i (black telephone):

Logging in:

1. Press the *Login/Logga in* button
2. Enter your extension number
3. Press the down arrow
4. Enter your four-digit PIN code
5. Press the right arrow for *Indicatel Ange*

Logging out:

1. Press the *Login/Logga in* button
2. Press the down arrow
3. Press the right arrow for *Indicatel Ange*

For the Aastra 4422 (grey or white telephone)

Logging in:

1. Enter your extension in the display after the text *Login with number/ Logga in med nr:*
2. Press the speaker button on the lower left
3. Enter your four-digit PIN code
4. Press the speaker button on the lower left

Logging out:

1. Press the C button on the lower right
2. When *Logout?!/Logga ut?* Shows in the display, press the speaker button on the lower left.